

DIY WOODEN BOOK NOOK-MF04

惊奇玩具店

Amazing Toys Store



Ages 14+

安全警告

- 为了保障您在娱乐时的安全,请在拼装之前阅读说明书。
- 此产品适合14周岁以上的人群,儿童必须在父母指导下组装。
- 在未经授权的情况下擅自改变和修改本产品,将损害您有关本产品的权益。

Safety Warning

- To keep your safe, please read this manual before you start.
- This product is suitable for people over 14 years old, children must assemble under the guidance of their parents.
- Any unauthorized alteration or modification of this product will damage your rights and interests related to this product.

注意事项

- 小心地从板上取下配件,防止零件断裂。断点可以用磨砂棒磨平。
- 不要一次性将木板零件全部拆下来。产品需配合无毒环保胶水组装,胶水黏贴后须静置2小时达到最强固化,黏贴后请勿随意挪动否则前功尽弃,建议先进行黏贴部件后再组装其他接插件以节省等待时间。
- 本产品接插口的松紧程度是由加工工艺,环境的温湿度决定的。接插部位如果是安装过紧,则需用指甲锉刀将接口部位打磨再组装;如果安装过松,则需在组装后加胶水进行固定。
- 儿童在组装时需要成人陪同。
- 说明书上含有重要信息,请予以保留。

Attentions

- Carefully remove the accessories from the board, prevent parts from breaking. The break point can be smoothed with a frosting rod.
- Do not detach all the parts at one time. Glue need be used at some points. After the glue is pasted, leave the product untouched for two hours to ensure a firm paste. To save time, you can do the pasting step first and then assemble the rest of the plugins.
- The tightness of the connector is determined by the processing technology and the temperature and humidity of the environment. If the splicing part is too tight to be installed, You can polish it with a file before assembling it; If the installation is too loose, you can use glue to fix it after assembly.
- Children need to be accompanied by adults when assembling.
- Please keep this manual for future reference.

维护和保养

- 请勿将此产品靠近热源或浸入水中。并使用干净柔软的布清洁此产品。
- 请勿使用擦窗剂、喷雾剂、溶剂、酒精、氨水、研磨剂等化学清洁剂来清洁产品。




Maintenance

- Do not place the product near heat or in water. And use a clean soft cloth to clean the product..
- Do not use the chemical cleaners to clean the product, such as window cleaners, sprays, solvents, alcohol, ammonia, abrasive and so on.


注意:感谢您在本店购买产品。若您拿到包裹,发现零件缺失或损坏,可与您购买的店铺客服联系或者联系此售后邮箱:booknook.aftersales@hotmail.com (记得提供您的订单编码,您购买的店铺名称以及订单截图。)

Notes:Thank you for purchasing product from our store. If you get the package and find parts missing or damaged, you can contact the customer service of the store you purchased from, or contact the following after-sales email address: booknook.aftersales@hotmail.com (Remember to provide your order number, the name of the store you purchased from and a screenshot of your order.)

● 配件 Accessories

 LED 灯 LED Light*1	 触摸线 Touch line*1	 电池盒 Battery box*1
 贴纸*2 Sticker*2	 磨砂棒 Frosted rod*1	 PVC*2
 黄色珠子 Yellow bead*1		

● 板材清单 Wood Block List



Attention



Handle Accessories Carefully

STEP 1

***拼装前请验证LED灯是否可以正常工作。**

Before assembling, please check the LED lights can work properly.

如图所示, 在开始组装之前, 请用电池测试灯具的供电装置是否能正常工作。


测试方法如下:

1. 将LED灯的导线端口和触摸感应板的导线端口连接到电池盒的相应端口;
2. 插入两节7号电池;
3. 触摸触摸传感器面板。如果灯能工作, 说明灯的供电装置没有问题; 如果灯不能正常工作, 请联系客服更换。

As shown in the picture, before starting to assemble, please use the batteries to test whether the light's power supply unit can work properly.


The test method is as follows:

1. Connect the wire port of the LED light and the wire port of the touch sensor panel to the corresponding port of the battery compartment;
2. Insert two AAA batteries;
3. Touch the touch sensor panel. If the light work, it means there is no problem with the light's power supply unit; if the light does not work properly, please contact customer service for replacement.




STEP 2

辅助取件+辅助按压
Assisted Pickup+
Assisted pressing



STEP 3



STEP 4

注意:红色编码的零件为备用件,下同
Note: The parts numbered in red are spare parts the same below.



C13

C17

C16

STEP 5

C19

C29

C18

C12

STEP 3

STEP 2

C14

STEP 4

STEP 6

A7

A14

A9


A14

A6


A8

A5


STEP 7




STEP 8



STEP 9



STEP 10



STEP 11



STEP 10


STEP 12



STEP 13




STEP 14




STEP 15




STEP 16



STEP 17




STEP 18




STEP 19




STEP 20



STEP 21



STEP 22




STEP 23



STEP 24


将PVC两面的保护膜撕下再粘贴。
Tear off the protective film on the both side before stick it.




STEP 25

将PVC两面的保护膜撕下再粘贴。


Tear off the protective film on the both side before stick it.



STEP 26



贴纸*2
Sticker*2



STEP 25

STEP 24



STEP 23

C9

为确保门的推拉顺畅，将贴纸沿着门上下的边缘粘贴
For the door could work smoothly, please stick the paster along the edge of the door carefully.

STEP 27

完成!将2节7号电池放入电池盒中，按下触摸面板，即可开灯。


Put 2 AAA batteries into the battery box, press the touch sensor panel to turn on the light.



STEP 26



11





书店往事
Bookshop Memories



猫头鹰书店
Owl Bookstore



猫伯爵书房
Count Cat's Study

